

- Parts needed continued: Dash wiring harness from car with navigation and bose (you need the connectors unless you can figure out a better way to get them, non-navi to navi have different ones)



Quick visual comparison between non-navigation head unit and navigation head unit (left is navi, right is non-navi) AC amps are exactly the same (the upper white boxes) so no splicing required for those:

