

**Step by Step Instructions:**

1. Located the connectors in the dash wiring harness that you'll need, they are grouped together off of the same branch so once you find 1, the rest are nearby. I recommend finding the RGB Connector or USB connectors to get you in the right area, below is a screenshot of the USB (looks very similar to the RGB cable)



2. Remove all the electrical tape, conduit, etc. to expose all the connectors you need (M209, M210, M208, M75, M385). This is where you will want to refer to the AV.PDF I mentioned earlier to know what M209, M209, etc. mean. These will all plug into the back of the head unit (M75 plugs into the back of the screen along with one end of the RGB cable). You do not actually need the USB cable since the one from your current setup fits, it is just very tight and you may want this cable to run to the USB port in your arm rest if you need to (it took some finagling but I got mine to reach).