

****POINT OF NO RETURN AFTER THIS, NEXT STEPS WILL BE WHERE WE SPLICE INTO THE VEHICLES WIRING. MAKE SURE YOU USE A MULTIMETER TO CHECK ALL SPLICED CONNECTIONS TO MAKE SURE EVERYTHING IS CONNECTED PROPERLY AND THERE ARE NO SHORTS.**

4. The telephone adapter unit and XM radio satellite module are in the trunk on the underside of the rear shelf. We need to splice into the telephone adapter units microphone cable and the XM radio antenna from there and run it to the head navigation unit because these modules are built in on the new navigation systems. Remove the trunk rear plate, rear left wheel house finisher, trunk front finisher upper in the picture below items 7,2&9 (INT.PDF will help out a bit from the nico website I mentioned earlier where you go the AV.PDF)

