

6. Splice female ¼" headphone plug into connector on telephone adapter unit, pin out can be found in AV.PDF under Bose without navigation section. (I'm always going to refer to the AV.PDF so I don't make any typos on which pin does what). Splice the male ¼" headphone plug connector onto the head unit connector M210, again refer to AV.PDF for pin out. When done it'll look like this (FYI telephone adapter unit & XM satellite tuner is the silver boxes):



M210 connector with male connector (MAKE SURE GROUND GOES TO GROUND, SIGNAL GOES TO SIGNAL, ETC):

