

7. Run the new microphone wire and XM Satellite wires to the front of the car, I recommend the access hole in the upper left corner, just pull out the foam block, run the wires through, reach in the gap behind the rear seat on the inside of the car and pull them through. You can reinsert the foam block afterwards. You can also figure out how to run the wires on under the trims yourself, I can't tell you everything 😊

