

21. Push all the old unused non-navi connectors to the bottom as best you can, there are also some pockets in the bottom left and right corners which work nicely. Make sure you have the microphone extension cable connected to the male connector on M210. Connect M208, M209, M210, USB, GPS Antenna, AM/FM Antenna, XM Antenna, RGB connector and slowly push the stereo into its mounted position, this may take a bit. Take your time so that you don't pinch anything.
22. Once you eventually get it into position, connect the M75 and RGB cable into the back of the touch screen and put that into position, insert the top screws that hold the screen and head unit into position, insert the bottom 2 screws with a magnetic screw driver which holds the head unit into position. Install the new screen bezel with navigation buttons. At this point you should be here:



23. Install the 2 screws at the bottom of the screen bezel which holds it in place. Connect the radio/climate control connectors and reinstall the controls. Install the 2 screws and reinstall the cover that goes under the controls.