

8. You can replace all the panels in your trunk, we are done back here (you could wait until you are completely done just in case you need to troubleshoot).

If you can't figure out how to remove your head unit without pictures you probably shouldn't be doing this, I'll describe below but it is pretty easy.

9. Remove the cover under the climate controls, and then remove the 2 screws that become exposed. Disconnect the connectors connecting it and put it aside.
10. Remove the 2 screws holding the screen bezel/control buttons and pull gently while jiggling side to side to remove it.
11. Remove the 2 screws on the brackets below the screen to remove the screen; you will need to disconnect 1 wiring harness from the back of it.
12. Remove the 2 screws below the head unit; you should probably use a magnet screw driver to be able to pull the screws out.
13. Pull the non-navigation head unit out and disconnect all the harnesses (uses a little finessing to get it out) I also recommend putting down a towel or cloth so that you don't scratch your shifter finisher cover. Picture below of non-navi Bose head unit being removed:

