PINOUTS for Device to Sealevel RS 422 to USB converter