



Menzerna Innovation



Scratch resistant coatings are the greatest challenge for all coating repair systems. Menzerna's PO 85 RD 3.x, PO 106 FF, PO 85 RE 5 and PO 85 RD are addressing the special requirements of this new coating generation. Our formulations have been designed to remove sanding marks on scratch resistant coatings quickly and effectively, while leaving a brilliant finish that is haze and hologram free.

Product Summary

I			Properties			Type of Coating			Designed to	
	Formula	Designation	silicone free	Cut	Gloss	Colour	OEM Coatings	Repair Coatings	Aged/weather- worn Coatings	remove minimum sanding grit size
Compounding	22984	PO S 34 A	•	5,0	1,5	white		•	•	1.000
Polishing	22106	PO 91 L	•	3,5	3,0	white		•	•	2.000
	22923	PO 85 RD 3.01*	•	3,5	3,0	white	•			2.000
	22968	PO 85 RD 3*	•	3,0	3,5	white	•			2.500
Finishing	22029	PO 85 U	•	3,0	4,0	white	•	•		2.500
	22117	PO 73 CP		2,0	4,0	yellow		•	•	n.a.
	22865	PO 106 FF*	•	2,5	5,0	grey	•			2.500
	22972	PO 85 RE 5*	•	2,0	5,0	grey	•			3.000
	22992	PO 85 RD*	•	1,5	5,0	grey	•			3.000
Protection	22870	APO 60		1,0	5,0	yellow			•	n.a.
	22083	PO 73		0,0	5,0	yellow			•	n.a.

Cut/Gloss 1 =low 5 =high *Designed for scratch resistant coatings

Polishing Tips



- Never mix polishes on a foam pad and never use a pad you've used for compounding for polishing.
- It is important to apply adequate pressure on the buffer for the first passes over the surface. Pressure is required to cut through the swirl marks and/or surface imperfections.
- Compounding, polishing and finishing are different polishing methods
 that do not necessarily have to be applied consecutively. The appropriate
 combination of polishing steps depends on colour and quality of the
 coating aswell as on the required quality of the surface.

menzerna GmbH & Co. KG

P.O. Box 60 76468 Oetigheim Germany Phone: +49-7222-9157 0 Fax: +49-7222-9157 10 office@menzerna.com www.menzerna.com



Coating Repair System

Application Technique

				1000				
/////	Compounding	Polishing	Finishing*	Protection				
Application	The compounding	Polishing removes the	Eliminates sanding	Paint protection is the				
	process uses a rubbing	swirl marks left in a	marks from spot repair	application of a sealant				
20 St. 20	compound to effectively	painted surface by compo-	and produces a micro-	to preserve a vehicles				
(0)	remove scratches left in	unding. Polishing requires	scratch free high gloss	finish.				
	painted surfaces from	a buffer with a foam	finish.					
	sanding. Compounding	polishing pad. In hand						
	is followed by polishing	polishing, polish is applied						
	and/or paint protection.	with a foam polishing pad.						
Fresh OEM coatings	Removal of paint defects on fresh OEM coatings							
Grit size of sanding paper:		2.000	2.500 - 3.000					
Polishing pad:	not applicable	lambskin, felt disc,	lambskin, waffle pad or	not applicable				
		foam pad	plain soft pad					
Menzerna polishes:		PO 85 RD 3.01	PO 106 FF					
Fresh repair coatings	Removal of overspray and paint defects on fresh repair coatings							
Grit size:	1.000 - 1.500	2.000	not applicable					
Polishing pad:	lambskin, felt disc,	lambskin, felt disc,	microfibre pad, waffle	lambskin,				
	foam pad	foam pad	pad or plain soft pad	foam pad				
Menzerna polishes:	PO S 34 A	PO 91 L	PO 85 U	PO 73				
Weather-worn coatings	Removal of scratches and reconditioning of weather-worn coatings							
Grit size:	1.000 - 1.500	not applicable	not applicable					
Polishing pad:	lambskin, felt disc,	lambskin,	lambskin,	lambskin,				
	foam pad	foam pad	foam pad	foam pad				
Menzerna polishes:	PO S 34 A	PO 91 L	PO 85 U	PO 73				

 $[*]good\ surface\ conditions\ may\ allow\ the\ application\ of\ the\ finishing\ compound\ directly\ after\ compounding/polishing$

Packaging Information				Laskpolite	
	Bot	tles	Cans	Drums	
Volume:	1 liter	0,5 liter	5 liters	30 liters	
Weight:	1,0 – 1,3 kg*	0,5 - 0,65 kg**	5,0 - 6,5 kg**	30,0 - 39,0 kg**	
Height:	240 mm	205 mm	250 mm	400 mm	
Length / Diameter:	80 mm	60 mm	185 mm	380 mm	
Width:	-	-	140 mm	-	
Diameter of the opening:	20 mm	20 mm	35 mm	n.a.	
Quantity per case:	6	10	n.a.	n.a.	

**depending on formulation density

P.O. Box 60 76468 Oetigheim Germany Phone: +49-7222-9157 0 Fax: +49-7222-9157 10 office@menzerna.com www.menzerna.com